



ELECTRICAL SYSTEM CIRCUIT DIAGRAM

1. Front signal lights
2. Headlights for high beam, low beam and parking light
3. Horn
4. Side turn signals
5. Brake light push switch
6. Contactor for fuel reserve indicator light
7. Indicator
8. Battery
9. Indicator for warning light system
10. Wiper engine
11. Fuses for electrical system protection
12. Fuse for high beam
13. Push switch on driver's side door post for lamp 26
14. Switch for turn signals
15. Horn push button
16. Switch for headlights and flasher
17. Ignition starter switch
18. Indicator light for turn signals
19. Lamp for illumination of the instrument cluster
20. Indicator light for parking and tail light
21. Alternator charge indicator light
22. Indicator light for the fuel reserve
23. Indicator light for too low lubricating oil pressure
24. Control lamp for headlight high beam
25. Switch for exterior and instrument lighting
26. Lamp in the rearview mirror
27. Switch for warning light system
28. Warning light system indicator light
29. Wiper switch
30. Alternator regulator group
31. Alternator
32. Starter
33. Ignition coil
34. Spark plug
35. Ignition distributor
36. Contactor for indicator light of too low lubricating oil pressure
37. Rear tail, brake and turn signal lights
38. Registration plate lamp

IDENTIFICATION COLORS OF THE CABLES

Azzurro = Light blue	Grigio = Grey	Rosa = Pink
Bianco = White	Marrone = Brown	Rosso = Red
Giallo = Yellow	Nero = Black	Verde = Green

INT - INTER = **Switch**

The symbol ■ indicates that the cable is provided with an identification number tape or sleeve.

www.AXEL-GERSTL.de

www.AXEL-GERSTL.de